
## **RECOMMENDED TOOLS**










MODEL NO.: F01 104 DESCRIPTION: SINGLE HANDLE LAVATORY FAUCET



#### Faucet installation




to the base of faucet. Fix the 3 screws #20 by screwdriver.

2.Assemble the 2 flexible hose to the faucet with adjustable wrench.

3.Connect the flexible hose to water supply valve (not included), and tighten it with adjustable wrench. DON'T OVER TIGHTEN! Caution: make sure connect the hot and cold supply lines to supply valves correctly. Warning: The supply valves are not included, please purchase them in plumbshop.

# Parts list



1 3/4"

Ø1 <u>3/8</u>″

12 1/2"

1 1/2"MAX


NO.	PART NAME
1	Handle
2	Screw
3	Index
4	Trim cap
5	Cartridge lock nut
6	Cartridge
7	Flow restricter
8	Screen filter
9	O-ring
10	Cartridge seat
11	Screw
12	O-ring
13	Aerator
14	Body
15	O-ring
16	Threaded sleeve
17	Copper tube
18	Gasket assembly
19	Lock nut
20	Screw
21	Aerator wrench
22	Allen key
23	Flexible hose

8

Ø1 <u>3/8</u>"

4 5/8

### **Checking and testing**



1. Turn the faucet handle all the way on, turn on hot and cold water supply and flush water lines for one minute. 2. Check all connections at arrows for leaks, re-tighten it if necessary. BUT DON'T OVERTIGHTEN

1.Put the faucet into the installation hole of the basin. Make sure o-ring be on the base of faucet. Assemble gasket assembly #18 and lock nut #19